DRS-480 series

480W All-In-One Intelligent Security Power

User's Manual
Click Me



UL62368-1 BS EN/EN62368-1 AS/NZS 62368.1 TPTC004 IEC62368-1

Security Network Telecom Automate Industrial

Features

- Universal input 90~305VAC (277VAC available)
- All-in-one function with Power supply, DC-UPS, battery charger and status monitoring in ONE compact unit
- Signal and alarms design meet UL2524,NFPA 1221,BS EN/EN54-4 and GB17945 requirement, with adjustable parameters configurable by communication interface
- Form C relay contacts and LED indicators for AC Fail, Battery Low, Charger Fail, and DC-OK
- Load-dependent high speed battery charging
- Built-in MODBus or CANBus protocol
- Protections: Short circuit / Overload / Over voltage / Over temperature(auto derating) / Battery reverse polarity (No damage) / Battery cut off
- Battery low protection / Battery reverse polarity protection
- -30 ~ +70℃ wide operating temperature
- Cooling by free air convection
- Can be installed on DIN rail TS-35/7.5 or 15
- Charging curve can be set with SBP-001(only for CANBus model)
  (Smart programmer sold separately, please refer to: https://www.meanwell.com/webapp/product/search.aspx?prod=SBP-001)
- 20~100% charging current adjustable by VR
- 2 or 3-stage selectable by DIP S.W
- Suitable for lead acid and lithium-ion batteries
- 3 years warranty

Applications

- Public safety battery back-up (Red box)
- Security system
- Emergency lighting system
- Alarm system
- Uninterruptible DC-UPS system, battery detection system
- Central monitoring system
- Industrial automation

GTIN CODE

MW Search: https://www.meanwell.com/serviceGTIN.aspx

Description

DRS-480 is a 480W AC/DC DIN rail type security power supply series. In addition to the primary output, there is an additional charger circuit that will automatically adjust charge current depending on the primary output current. DRS-480 accepts the universal input between 90VAC and 305VAC, and supports output 24VDC, 36VDC, and 48VDC nominal systems. With high efficiency up to 93.5%, it can operate with free air convection cooling under -30℃ through 70℃ ambient temperature. In addition to the key protection features such as overload protection, over voltage protection, battery low voltage disconnect, and battery reverse polarity protection, the DRS-480 also provides Form-C contacts and LED indicator alarm signals for AC-fail, battery low, charger fail, and DC-OK to allow easy integration into security systems that comply with local alarm codes.

Model Encoding

DRS - 480 - 48 ☐

- Function option(Blank: Built-in MODBus, CAN: Built-in CANBus)
- Output voltage(24V/36V/48V)
- Rated wattage
- Series name

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

SPECIFICATION

MODEL			DRS-480-24□	DRS-480-36□	DRS-480-48□
			□=Blank, CAN		
OUTPUT	OUTPUT VOLTAGE Note.2		24V	36V	48V
	LOAD CURRENT RANGE		0 ~ 20A	0 ~ 13.3A	0 ~ 10A
	BATTERY CURRENT (CC)(max.)		15.4A	10.2A	7.7A
	RECOMMENDED BATTERY CAPACITY(AMP HOURS)Note.3		20 ~ 200AH	13 ~ 133AH	10 ~ 100AH
	TOTAL OUTPUT POWER Note.4		Combined power on all Channels must not exceed 480W, load has priority. 550W peak capability within 5s.		
	RIPPLE & NOISE (max.) Note.5		240mVp-p	360mVp-p	480mVp-p
	VOLTAGE TOLERANCE Note.6		±1.0%	±1.0%	±1.0%
	LINE REGULATION		±0.5%	±0.5%	±0.5%
	LOAD REGULATION		±0.5%	±0.5%	±0.5%
	SETUP RISETIME Note.7		2400ms, 1000ms/230VAC 2400ms, 1000ms/115VAC at full load		
	HOLD UP TIME (Typ.)		16ms/230VAC 10ms/115VAC at full load		
INPUT	VOLTAGE RANGE		90 ~ 305VAC 127 ~ 431VDC		
	FREQUENCY RANGE		47 ~ 63Hz		
	POWER FACTOR (Typ.)		PF>0.95/230VAC PF>0.98/115VAC at full load		
	EFFICIENCY (Typ.)		92.5%	93.5%	93.5%
	AC CURRENT (Typ.)		5.4A/115VAC 2.7A/230VAC		
	INRUSH CURRENT (Typ.)		COLD START 30A/115VAC 60A/230VAC		
PROTECTION	SHORT CIRCUIT		Protection type: Constant current limiting, power will shutdown after 5 sec, re-power on to recover.		
	OVERLOAD		105 ~ 135% rated output power		
			Protection type: Constant current limiting, shutdown output voltage after 5 sec.		
	OVER TEMPERATURE		Automatically drop load with temperature only for bat. load. Protection type : Shut down o/p voltage, recover automatically after temperature goes down.		
	OVER VOLTAGE		Load main output : 32.4 ~ 37.3V	Load main output : 48.6 ~ 55.9V	Load main output : 64.8 ~ 74.5V
			Protection type : Shut down o/p voltage, re-power on to recover		
	BATTERY CUT OFF		20.9±0.5V	31.3±0.7V	41.8±1V
	REVERSE POLARITY		By internal MOSFET, no damage, recovers automatically after fault condition is removed.		
FUNCTION	FORM-C RELAY	AC FAIL	Signals AC failure and activates when input voltage drops below : 79~89VAC of 120AC, 132~187VAC of 220VAC. Relay contact output, ON : AC OK ; OFF : AC Fail ; max. rating : 30Vdc/1A		
		CHARGER FAIL	Relay contact output, ON : Charger OK ; OFF : Charger Fail ; max. rating : 30Vdc/1A		
		DC OK	Signals normal DC output and activates when output voltage > 90% rated value. Relay contact output, ON : DC OK ; OFF : DC Fail ; max. rating : 30Vdc/1A		
		BATTERY LOW/ ABNORMAL/ DISCONNECTED	Relay contact output, ON : Battery OK ; OFF : Battery Low ; max. rating : 30Vdc/1A		
			Battery low voltage : < 22V±0.3V	Battery low voltage : < 33V±0.4V	Battery low voltage : < 44V±0.5V
	BATTERY START		Restart system directly from battery and does not require AC power		
	DC-UPS		UPS switch to battery power within 10ms of AC failure		
	ADJUSTABLE CHARGING CURRENT		20% ~ 100% charging current adjustable by VR		
	BATTERY TEMPERATURE COMPENSATION		The system can change the battery charging voltage by detecting the temperature (Please refer to page 9~10 for more details).		
ENVIRONMENT	WORKING TEMP.		-30 ~ +70℃ (Refer to "Derating Curve")		
	WORKING HUMIDITY		20 ~ 90% RH non-condensing		
	STORAGE TEMP., HUMIDITY		-40 ~ +85℃, 10 ~ 95% RH non-condensing		
	TEMP. COEFFICIENT		±0.03%/℃ (0 ~ 50℃) on Load output		
	VIBRATION		10 ~ 500Hz, 5G 10min./1cycle, 60min. each along X, Y, Z axes		
	OPERATING ALTITUDE Note.8		2000 meters / OVC Ⅲ		
	OVER VOLTAGE CATEGORY		Ⅲ; According to Dekra BS EN/EN62368-1; altitude up to 2000 meters		
SAFETY & EMC (Note.10)	SAFETY STANDARDS		UL62368-1, Dekra BS EN/EN62368-1, RCM AS/NZS 62368.1, EAC TP TC 004 approved		
	WITHSTAND VOLTAGE		I/P-O/P: 4KVAC I/P-FG: 2KVAC O/P-FG: 1.5KVAC		
	ISOLATION RESISTANCE		I/P-O/P, I/P-FG, O/P-FG: 100M Ohms/500VDC/25℃/ 70%RH		
	EMC EMISSION		**Parameter**	**Standard**	**Test Level / Note**
			Conducted	BS EN/EN55032 (CISPR32)	Class B
			Radiated	BS EN/EN55032 (CISPR32)	Class B
			Harmonic Current	BS EN/EN61000-3-2	-----
			Voltage Flicker	BS EN/EN61000-3-2	-----
	EMC IMMUNITY		BS EN/EN55035 , BS EN/EN61204-3, BS EN/EN61000-6-2(BS EN/EN50082-2)		
			Parameter	**Standard**	**Test Level / Note**
			ESD	BS EN/EN61000-4-2	Level 3, 8KV air ; Level 2, 4KV contact; criteria A
			Radiated	BS EN/EN61000-4-3	Level 3, 10V/m ; criteria A
			EFT / Burst	BS EN/EN61000-4-4	Level 3, 2KV ; criteria A
			Surge	BS EN/EN61000-4-5	Level 3, 1KV/Line-Line ;Level 3, 2KV/Line-Line-Chassis ;criteria A
			Conducted	BS EN/EN61000-4-6	Level 3, 10V ; criteria A
			Magnetic Field	BS EN/EN61000-4-8	Level 4, 30A/m ; criteria A
	FIRE DETECTION AND FIRE ALARM SYSTEM		Compliance to BS EN/EN54-4		
OTHERS	MTBF		556.6K hrs min. Telcordia SR-332 (Bellcore); 74.5K hrs min. MIL-HDBK-217F (25℃)		
	DIMENSION		110*125.2*150.7mm (W*H*D)		
	PACKING		1.92Kg; 6pcs/ 12.5Kg / 1.42CUFT		


NOTE

1. All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25℃ of ambient temperature.
2. Variable with charger voltage when battery is connected.
3. This is Mean Well's suggested range. Please consult your battery manufacturer for their suggestions about maximum charging current limitation.
4. If load current increases, the system will prioritize load current demand and automatically reduce the battery charging current.
5. Ripple & noise are measured at 20MHz of bandwidth by using a 12" twisted pair-wire terminated with a 0.1 μF & 47 μF parallel capacitor.
6. Tolerance : includes set up tolerance, line regulation and load regulation.
7. Length of setup time is measured at cold first start, Turning ON/OFF the power supply may lead to increase of the setup time.
8. The ambient temperature derating of 3.5℃/1000m with fanless models and of 5℃/1000m with fan models for operating altitude higher than 2000m(6500ft).
9. Installation clearances : 40mm on top, 20mm on the bottom, 5mm on the left and right side are recommended when loaded permanently with full power. In case the adjacent device is a heat source, 15cm clearance is recommended.
10. The power supply is considered a component which will be installed into a final equipment. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as available on https://www.meanwell.com//Upload/PDF/EMI_statement_en.pdf)


※ Product Liability Disclaimer : For detailed information, please refer to https://www.meanwell.com/serviceDisclaimer.aspx

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000


Block Diagram



Derating Curve



Static Characteristics



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

■ Function manual

1.Alarm signals

(1) Alarm Signal is sent out through " AC fail " & " Battery low " & " Charger fail "pins via relay contact.

(2) An external voltage source is required for this function. The maximum applied voltage is 30Vdc and the maximum sink current is 1A. Please refer to Fig 1.2.

(3) Table1.1 explains the alarm function built in the power supply

INPUT	AC fail		DC OK		Battery low/Abnormal /Disconnected		Charger fail	
	2-3	1-3	5-6	4-6	8-9	7-9	11-12	10-12
AC only	closed	open	closed	open	open	closed	-----	-----
AC + BAT.	closed	open	closed	open	closed	open	-----	-----
BAT. only	open	closed	closed	open	closed	open	-----	-----
Low BAT. (<30% capacity)	-----	-----	-----	-----	open	closed	-----	-----
Charger Fail	-----	-----	-----	-----	-----	-----	open	closed

Table 1.1 Explanation of alarm signal





Fig 1.1 alarm signal Terminals




External voltage source (V) and resistor (R)
(The max. Sink is 1A and 30Vdc)

Fig 1.2 Internal circuit of AC fail (Battery low), via relay contact

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

2.DC-UPS function

When AC mains drops below:79~89VAC of 120VAC,132~187VAC of 220VAC, UPS function will activate and power source switch battery backup.




3.Charger setting

3.1.1 2 or 3-stage selectable by DIP S.W


※ This series provides 2 or 3 stage charging curve.

1	OFF: 3 stage(Default), ON: 2 stage
2	Charging curve adjustable:see below
3	




3.1.2 Charging curve can be adjustable by DIP S.W

◎ **2 stage** charging curve



◎ Default **3 stage** charging curve



State	DRS-480-24□	DRS-480-36□	DRS-480-48□
Constant Current	15.4A	10.2A	7.7A
Vboost	28.8V	43.2V	57.6V

◎ Suitable for lead-acid batteries (flooded, Gel and AGM) and Li-ion batteries (lithium iron and lithium manganese).

State	DRS-480-24□	DRS-480-36□	DRS-480-48□
Constant Current	15.4A	10.2A	7.7A
Vboost	28.8V	43.2V	57.6V
Vfloat	27.6V	41.4V	55.2V

◎ Suitable for lead-acid batteries (flooded, Gel and AGM) and Li-ion batteries (lithium iron and lithium manganese).

※ The default curve is programmable, whereas other pre-defined curves can be activated by the means of the DIP S.W; please refer to the table below and the Mechanical Specification.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

◎ Embedded **2 stage** charging curve

DIP SW position		**24V model**		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	15.4A	28.8
ON	OFF	Pre-defined, gel batter		28.0
OFF	ON	Pre-defined, flooded battery		28.4
ON	ON	Pre-defined, AGM battery,LiFe04		29.2
DIP SW position		**36V model**		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	10.2A	43.2
ON	OFF	Pre-defined, gel battery		42
OFF	ON	Pre-defined, flooded battery		42.6
ON	ON	Pre-defined, AGM battery,LiFe04		43.8
DIP SW position		**48V model**		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	7.7A	57.6
ON	OFF	Pre-defined, gel battery		56.0
OFF	ON	Pre-defined, flooded battery		56.8
ON	ON	Pre-defined, AGM battery,LiFe04		58.4

◎ Embedded **3 stage** charging curve

DIP SW position		**24V model**			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	15.4A	28.8	27.6
ON	OFF	Pre-defined, gel batter		28.0	27.2
OFF	ON	Pre-defined, flooded battery		28.4	26.8
ON	ON	Pre-defined, AGM battery,LiFe04		29.2	28.0
DIP SW position		**36V model**			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	10.2A	43.2	41.4
ON	OFF	Pre-defined, gel battery		42	40.8
OFF	ON	Pre-defined, flooded battery		42.6	40.2
ON	ON	Pre-defined, AGM battery,LiFe04		43.8	42.0
DIP SW position		**48V model**			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	7.7A	57.6	55.2
ON	OFF	Pre-defined, gel battery		56.0	54.4
OFF	ON	Pre-defined, flooded battery		56.8	53.6
ON	ON	Pre-defined, AGM battery,LiFe04		58.4	56.0

3.2 SBP-001 can adjust the charging curves (Only CANBus Model)

◎ **2 stage** charging curve (programable)

DIP SW position		**24V model**		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	15.4A	28.8
DIP SW position		**36V model**		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	10.2A	43.2
DIP SW position		**48V model**		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	7.7A	57.6

◎ **3 stage** charging curve (programable)

DIP SW position		**24V model**			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	15.4A	28.8	27.6
DIP SW position		**36V model**			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	10.2A	43.2	41.4
DIP SW position		**48V model**			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	7.7A	57.6	55.2


※ SBP-001 is a programmer, particularly for MEAN WELL's various programmable battery charger models to program the parameters of charging curves, such as the Constant current (CC), tapper current(TC), Constant voltage (CV), float voltage (FV) and so on, to accommodate the diversified battery specification in industry. With the design accounting for simplicity and convenience, users can easily configure MEAN WELL's programmable battery chargers with SBP-001 programmer and the computer; all of the setups are able to be finished easily by the means of the specific software.

Note:(1) Tapper current(TC) default is 10%, can be fine tuned from 2% to 30% by SBP-001 with computer or CANBus Interface.


(2) The SBP-001 only supports CANBus version(DRS-480-xxCAN).

(3) Please contact MEAN WELL for more details.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000




※ **User Interface**:



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

※ Communication cable for DRS series





DRS series pin assigment :

Connector	Pin Assigment									
SBP-001 10pin connector (Connector part No.:HRS DF11-10DS) 	1	2	3	4	5 (CANH)	6 (CANL)	7	8	9	10 (GND)
DRS-480 RJ45 Communication port 	-----	-----	-----	-----	6	7	-----	-----	-----	8
Wire color	-----	-----	-----	-----	Green	White/Brown	-----	-----	-----	Brown


3.3 Communication interface

Charging parameters can be modified by MODBus (DRS-480-xx) or CANBus(DRS-480-xxCAN) communication commands.
For details, please refer to: http://www.meanwell.com/manual.html

4.Power Boost Mode


The maximum current on the load output is the 2 times the rated current for 4 minutes max. and 3 times the rated current for 4 seconds max.
For example (48V model):

Output load



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

5.Battery temperature compensation



◎ To exploit the temperature compensation function, please attach the temperature sensor(NTC) which is enclosed with DRS-480, to the battery or the battery's vicinity.
◎ DRS-480 is able to work normally without the temperature sensor(NTC).

5.1 The compensation parameters included Disable, -3, -4 and -5mV/ ℃ /Cell .It can be modified by communication command of CANBus, MODBus. The factory default value is -3mV/ ℃ /Cell.

5.2 It will be regarded as normal temperature and will not be compensated when temperature compensation resistance is not connected; And temperature compensation will only compensate lead-acid battery, not lithium iron battery.

5.3 The range of temperature compensation is 0-40℃ , normal temperature 25℃ is the central value, no compensation; When the temperature is < 0 ℃ or > 40 ℃, the current temperature compensation value will be limited to 0 ℃ or 40℃.

24V model as an example

Assuming that V_{boost}=28.8V, temperature compensation set to -5mV/℃/Cell by communication, TEMP_bat is NTC temperature detection.

The compensating voltage can be calculated by the following equation:

V_{boost_comp}=28.8V-5mV*(TEMP_bat -25℃)*12Cell

Max. compensation voltage:

V_{boost_H}=28.8V-5mV*(0℃-25℃)*12Cell=30.3V



Min. compensation voltage:


V_{boost_L}=28.8V-5mV*(40℃-25℃)*12Cell=27.9V

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

5.4 Accessory List

※ NTC Sensor and mating wire along with DRS-480 (Standard accessory)

	Item	Quantity
1	NTC sensor wire Part No.: NSG05C250J5 	1
2	Mating wire  JS-2007-2*4-T or equivalent	1

Connection Diagram


Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

6.LED alarm

Function		Description	Output of alarm
DC OK		DC fail	OFF ○
		DC OK	Green ●
AC fail		AC fail	Red ●
		AC OK	OFF ○
Status	Charging status	Float	Green ●
		Charging: CC/CV	Orange ●
	System diagnosis	Discharging	Orange: 1 Blink/Pause
		Charger fail	Red : 1 Blink/Pause
		Battery overvoltage / Battery reverse polarity	Red : 2 Blink/Pause
		Battery low / No Battery	Red : 3 Blink/Pause
		Battery discharge peak power timeout.	Red : 4 Blink/Pause
		Over load / short	Red : 5 Blink/Pause
		Over temperature	Red : 6 Blink/Pause
		Timeout	Red : 7 Blink/Pause

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

■ Suggested Application

1.Backup connection for AC interruption

(1) Please refer to Fig2.1 for suggested connection.

The power supply charges the battery and provides energy to the load at the same time when AC mains is OK.

The battery starts to supply power to the load when AC mains fails.




Fig 2.1 Suggested system connection

(2) Backup time

Backup time depends on:

※ from the load current

※ from the size of the batteries.

The following table is an example (battery capacity at C10 discharge rate).


Load \ Battery	10AH	20AH	50AH	100AH	200AH
1.5A	350min	13h	33h	67h	133h
3A	125min	350min	17h	33h	67h
5A	60min	180min	600min	20h	40h
7.5A	35min	90min	350min	13h	27h
10A	23min	60min	240min	10h	20h
15A	13min	35min	125min	350min	13h

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

■ Mechanical Specification

(Unit: mm , tolerance ± 1mm)

Case No. 214C




Terminal Pin No. Assignment (TB4)

Pin No.	Assignment
1,2,3	AC fail
4,5,6	DC OK
7,8,9	Battery low/ Abnormal/ Disconnected
10,11,12	Charger fail


Terminal Pin No. Assignment (TB3)

Pin No.	Assignment
1,2	+V
3,4	-V



Terminal Pin No. Assignment (TB2)

Pin No.	Assignment
1,2	BAT.-
3,4	BAT. +



Terminal Pin No. Assignment (TB1)

Pin No.	Assignment
1	FG ⏚
2	AC/N
3	AC/L

Force button Connector (CN12):
JS-2008R-4*2-T or equivalent


Pin No.	Assignment
1	3.3V
2	GND
3	RTH+
4	RTH-
5	A0
6	A1
7,8	Open: Normal Short: Force start

Terminal Pin No. Assignment (RJ45)

Pin No.	Function	Description
1,2,3,4,5	NC	Retain for future use.
6	D-/DB	For MODBus model:Serial Date used in the MODBus interface.
	CANH	For CANBus model:Date line used in the CANBus interface.
7	D+/DA	For MODBus model:Serial Clock used in the MODBus interface.
	CANL	For CANBus model:Date line used in the CANBus interface.
8	GND-AUX	Auxillary voltage output GND. The signal return is isolated from the output terminals(+V & -V).

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

■ Installation Instruction



Back View

This series fits DIN rail TS35/7.5 or TS35/15.
For installation details, please refer to the Instruction manual.

ADMISSIBLE DIN rail:TS35/7.5 OR TS35/15
(For reference only. Not included with unit.)

■ Installation Manual

Please refer to : http://www.meanwell.com/manual.html

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000